

SUB-METER INSTALLATION INSTRUCTIONS

NOTES:


Your sub-meter may be located on the property to be served, or within the designated well easement. If your sub-meter is installed on the property to be served it must be:

1. Located within three (3) feet of the property line, or back of curb; and
2. Ahead/Upstream of any and all connections to your service water line; and
3. Include all water used on the property; and
4. Accessible by Nevada Division of Water Resources (Office of the State Engineer) staff.


Please contact the Division of Water Resources prior to installation if you have any questions or concerns regarding submeter location.

Installation of a sub-meter shall not be considered a replacement of or in lieu of the main water meter, required by the State Engineer water right permit. Furthermore, if any meter required by the State Engineer fails to operate properly, it must be repaired or replaced within thirty (30) days.

If you have any questions please call the Division of Water Resources at (702) 486-2770.




EXAMPLE 1



⊗ = METER


EXAMPLE 2




⊗ = METER

SUB-METER INSTALLATION INSTRUCTIONS


EXAMPLE 3



 = METER


WELL EASEMENT
SUB-METER DISTRIBUTION

EXAMPLE 4



 = METER

EXAMPLE 5



 = METER